




1. Fixing with screw as shown.



2. Adjust panel's position and fix it with screw as shown.



3. Fixing basket as shown.



4. Fix the slice as show. Be sure slide moving smoothly.

